


BERGEN
















Diagram illustrating assembly instructions and warnings:

- Warning 1:** A crossed-out power drill icon indicates that a power drill should not be used for assembly.
- Warning 2:** A crossed-out icon of a rectangular block being drilled into a surface indicates that the chair should not be placed on a soft surface like a rug or carpet.
- Time:** A clock icon with the text "15'" indicates that the assembly time is 15 minutes.
- Person:** An icon of a person with the text "1" indicates that one person is required for assembly.




A	B	C	D
			
x 1	x 1	x 1	x 1

1



2



!

